

---

Subject: Re: 1pi or 2pi for surrounds?

Posted by [Wayne Parham](#) on Fri, 26 Aug 2011 17:40:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

All R13 is the same thickness, which is about 3" uncompressed. Remove the vapor barrier and attach it with white glue. Just run a bead back and forth on the inside panel, with the glue bead lines about 2" apart and lay the sheet of insulation on that. Push it in place and let it dry.

---