

---

Subject: Re: Midrange Horn

Posted by [Wayne Parham](#) on Fri, 26 Aug 2011 23:09:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It depends on the thickness of the veneer. If you're using thin veneer, you can cover the entire side before assembly. But thick veneers will create enough offset the pieces won't fit together well so you have to trim to fit. On those, it's best to cut the veneer to size before assembly, but don't actually attach it until after assembly. Honestly, the thinner veneers are easier to use for the flare pieces. Save the thicker stuff for the cabinet sides.

---