Subject: crossover board assembly Posted by dprice on Mon, 29 Aug 2011 22:20:48 GMT View Forum Message <> Reply to Message

Is there any trick to using the crossover PCBs? Do I just trim the leads to length and tack in place with solder? Or do I need to drill little holes to pass the leads through?

A close-up photo of one done right would be appreciated.

Page 1 of 1 ---- Generated from AudioRoundTable.com