

---

Subject: Re: 1pi or 2pi for surrounds?

Posted by [Wayne Parham](#) on Wed, 31 Aug 2011 03:40:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Answers by numbers:

1. Use #6 pan head screws to attach the drivers to the baffle. You can get them at any hardware store, like Lowes, Home Depot or Sutherlands and even some department stores like Target or Walmart. If you can't find them with a black finish, you can paint the heads black with enamel and a small paint brush, like what you might use to paint a model.
2. Cut a rectangular hole 2-1/8" x 2-7/8" for the connector panel. We put them on the center of the back panel, 3" from the bottom.
3. The port is 2-1/2" diameter. I remember including the tube you should use, so look for a cardboard tube in the box. It's about 9" long. Cut two 3-1/2" long tubes from this with a table saw and glue them onto the baffle.