Subject: Re: 1pi or 2pi for surrounds? Posted by Wayne Parham on Thu, 15 Sep 2011 12:49:23 GMT View Forum Message <> Reply to Message

Don't crossover to subs - blend them. Let the mains run full range and low-pass the subs. Flanking subs should be run up into the low 100's, more distant subs need to be cutoff lower to prevent localization cues.