
Subject: Re: Drapes or Curtains

Posted by [Wayne Parham](#) on Fri, 20 Jan 2012 15:43:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

To absorb bass frequencies, you'll need a panel absorber, like this:
"False Wall" panel absorbers
