

---

Subject: Re: Powering my PI Speakers

Posted by [dutchswan0311](#) on Fri, 17 Feb 2012 22:15:44 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Can you define "pushing it to the limit"? I would like to crank things up, and figured matching the wattage from amp to speaker WOULD maximize output, without risking someone accidentally blowing a driver by turning an amp to high. In this configuration, I figured "cranking the amp all the way" would utilize the maximum potential of the driver without risk of damage.

Is my approach wrong or misguided?

---