Subject: skywave's 3Pi subwoofer build Posted by skywave-rider on Thu, 01 Mar 2012 19:25:37 GMT View Forum Message <> Reply to Message

I am planning my 3Pi subwoofer build and I have a few questions regarding woofer mounting.

The Pi Subwoofer driver has 0.26", (6.6mm) mounting holes. What's the best thing to do...should I use all 8 mounting holes, t-nuts, and what size screws work best so as not to distort the mounting flange? I was thinking of getting these.

I am probably not recessing the woofer, and I will use a grill like this, requiring this sort of hardware, unfortunately.

AudioRoundTable.com

The cheaper plastic grill mounts would be less damaging to the baffle.

Any tips are appreciated.

Page 1 of 1 ---- Generated from