

---

Subject: Re: R13 insulation: what to do? spray glued down?

Posted by [steve f](#) on Sat, 17 Mar 2012 17:03:25 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I use Super 77 or DAP spray adhesive. Mostly for the faster tack. Plain old wood glue works fine.

---