Subject: Re: R13 insulation: what to do? spray glued down?
Posted by steve f on Sat, 17 Mar 2012 17:03:25 GMT
View Forum Message <> Reply to Message

I use Super 77 or DAP spray adhesive. Mostly for the faster tack. Plain old wood glue works fine.