Subject: Re: R13 insulation: what to do? spray glued down?
Posted by Wayne Parham on Tue, 20 Mar 2012 17:07:25 GMT
View Forum Message <> Reply to Message

It should be laying flat, spanning the cross-section. It sort of partitions the cabinet into upper and lower sections. Bass passes right through, but midrange is attenuated.