
Subject: Re: R13 insulation: what to do? spray glued down?
Posted by [Wayne Parham](#) on Tue, 20 Mar 2012 17:07:25 GMT
[View Forum Message](#) <> [Reply to Message](#)

It should be laying flat, spanning the cross-section. It sort of partitions the cabinet into upper and lower sections. Bass passes right through, but midrange is attenuated.
