

---

Subject: Re: 2 Pi plans

Posted by [Wayne Parham](#) on Tue, 22 May 2012 14:50:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Use R11 for internal stuffing material. Those acoustic wedges are fine for lining the walls of your listening room, but they don't work as well for loudspeaker damping material.

Kits include parts for one loudspeaker.

---