

---

Subject: Re: auralex wedges in place of R13  
Posted by [Wayne Parham](#) on Fri, 22 Jun 2012 02:57:40 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

No, don't use it. Use the R13 as described in the plans - lining the side, back and top or bottom (depending on model) and one sheet spanning the cross-section.

---