

---

Subject: Re: auralex wedges in place of R13  
Posted by [thatsnasty](#) on Thu, 28 Jun 2012 10:32:39 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Wayne is there anything else that will work in place of R13?

I'm in Canada and it's impossible to find that stuff here... I've looked everywhere. I can get R14 or similar insulation types around 3-3 1/2" thickness, but that's about it.

---