
Subject: Re: auralex wedges in place of R13
Posted by [Wayne Parham](#) on Thu, 28 Jun 2012 13:06:19 GMT
[View Forum Message](#) <> [Reply to Message](#)

R14 is fine. Just don't use any of those alternate materials. Fiberglass works best.
