

---

Subject: Re: aurallex wedges in place of R13  
Posted by [Wayne Parham](#) on Thu, 28 Jun 2012 13:06:19 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

R14 is fine. Just don't use any of those alternate materials. Fiberglass works best.

---