

---

Subject: Re: 4Pi with feet

Posted by [Wayne Parham](#) on Tue, 29 Oct 2013 00:18:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It shouldn't be hard to install the T-Nuts. Just drill the holes slightly smaller than the T-Nut shank, so there is an interference fit. The trick is to have a little bit of friction to provide some clamping force, but not so much that the threads strip when you pull them in. Use a dab of epoxy and pull 'em all in with a sacrificial screw. Change screws every three or four T-Nuts, so you don't damage the threads. Basically just follow the directions on the link a few posts back.

---