
Subject: Re: New Pi 4 + Pi 3 Sub buildout
Posted by [Wayne Parham](#) on Tue, 18 Mar 2014 19:44:43 GMT
[View Forum Message](#) <> [Reply to Message](#)

Pro amps generally need more preamp drive level than consumer gear. Your amp needs 1.4vrms input drive level to reach full power, and this is about twice the voltage commercial preamps deliver (0.775v).
