Subject: Re: 2 Pi Tower kits Posted by Bill Epstein on Sat, 26 Apr 2014 23:25:05 GMT View Forum Message <> Reply to Message

How you build depends on the tools and clamps you have but this is what I do, using braces cut on the same saw setting as the tops and bottoms to square it up. No fasteners, just Titebond and Butt Joints.

I just use dabs of glue to hold the insulation in place but I usually have to "convince" some pieces to stay put with 1/4" staples.

File Attachments
1) IMG\_2823\_1.JPG, downloaded 2160 times

## Page 1 of 1 ---- Generated from AudioRoundTable.com