Subject: Re: 4 Pi Build Progress

Posted by Wayne Parham on Fri, 04 Sep 2015 20:17:09 GMT

View Forum Message <> Reply to Message

You can use just about anything as a gasket under the crossover PCB. I personally use PVC liner, like what contractors put underneath shower tile. But you can use a sheet of cardboard, foam or pretty much anything that acts as a cushion. All we want to do is to prevent vibration.