

---

Subject: Re: tube rectifiers

Posted by [rohit](#) on Thu, 08 Jul 2004 21:59:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks for your reply, I think I prefer FREDs, but I do not understand why one would not want the DC level to raise to full value right away. If there were a surge as like happens from low resistance filaments in circuit, I could understand. There is not. Why is having full rail voltage on output tube plate during warmup of its filament a problem? Rohit

---