

---

Subject: Re: Popcorn ceiling?

Posted by [Wayne Parham](#) on Mon, 13 Mar 2017 04:03:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

A "popcorn ceiling" has features that are much too small to be acoustically significant. If you want to damp medium to high frequencies, use absorbent wedges.

---