

---

Subject: Re: Speaker Tweaks

Posted by [Wayne Parham](#) on Mon, 04 Dec 2017 22:45:25 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Good stuff, Barry. Thanks for providing feedback. This kind of information is really useful for others that face similar problems.

I often recommend 40mil PVC as gasket material, where needed. Some people cut gaskets out of cardboard too, and that's fine. Gaskets are recommended under crossover boards, under waveguides, etc. The only place a gasket isn't needed is where it's built-in, like on the midwoofers. In all other places, where hard surfaces might vibrate, gaskets are a good idea.

---