
Subject: 'cause it *IS* a myth...

Posted by [PakProtector](#) on Sat, 22 Jan 2005 02:46:47 GMT

[View Forum Message](#) <> [Reply to Message](#)

too many myths, too much confusion, too many 'rule of thumb' set out by folks who have too many of them(thumbs that is...).For a PP amp, this is the general set of design specs(in no particular order):good soundavailability of partsinexpensive, plentiful tubessane B+ (less than 400V, likely ~300)accessible design(no ridiculous tricks required)ease of troubleshootingfew parts10-20 Watts (with samll variation, 30)Class A bias of power stage1-man, single channel portabilityFor a general idea: 807's @ 280V/80 mA into 10k with 40% U-L screen taps. E-Linear connected 6BK7B phase splitter front end.For a bit more power, EL34 into 5k-6k6....or KT88/6550's at 350v/110 mA.Again, soooo many opinions as to what is the 'best' way and so many means of doing a very similar thing. It all depends on taste and a few basic requirements. What do you want? is one which ought to get answered first.regards,Douglas
