

---

Subject: Re: PSUDii tips

Posted by [Manualblock](#) on Mon, 31 Jan 2005 22:28:25 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I am confused again. Reading the Radiotron 3rd ed. It appears to say input voltage rating of power transformers should be made with the secondary fully loaded. What am I doing wrong if I may ask. Regarding Guenievre; I have printed out three different filament schematics. We are using the filament windings on the power trans; not the radio shack 12v trans is that correct? And I thought Golf was hard.

---