Subject: Re: Pi 3 Sub Plans Request
Posted by Wayne Parham on Sat, 05 May 2018 21:12:57 GMT
View Forum Message <> Reply to Message

I like to use 10-32 button-head screws and T-Nuts.

See the thread below for more information:
T-Nut installation