
Subject: Re: 3Pi Acoustic Axis and Listening Distance
Posted by [Symphonimind](#) on Sat, 14 Dec 2019 18:06:26 GMT
[View Forum Message](#) <> [Reply to Message](#)

Wayne Parham wrote on Sat, 14 December 2019 11:59 What I would define as the forward lobe centerline is the midpoint between the two vertical nulls. You can see in the video I posted in the message above exactly where those nulls occur. Watch the video for the position of the microphone above and below the speaker where you see a notch around 1.2kHz. The midpoint between them is the centerline of the forward lobe.

Thank you very much for your help. I will grab the last pair of 12PLB100 on the earth at Part Express to experiment with new high end 3Pis.

When I bought premade XO from your website, how much power the default XO can handle without smoking itself? If I want to use all what 12PLB100 can do, what upgrade I should do for XO to use safely at 600W RMS?

Edward.
