

---

Subject: Re: How to fasten R11/13?

Posted by [Wayne Parham](#) on Fri, 29 May 2020 20:30:32 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Remove the paper vapor barrier and glue the sheets in place with white glue. Just run a bead on the insulation and press it into place.

---