Subject: Re: 4pi flat pack, Rhino Line
Posted by jtwrace on Tue, 15 Sep 2020 21:14:33 GMT
View Forum Message <> Reply to Message

tubino wrote on Tue, 15 September 2020 16:05Thanks for posting these details!  It's very useful for me. Did you use 10-32 for the t-nuts, or 1/4" x 20?

1/4"-20 Tee Nuts for my driver.  However, if you are using a small Waveguide or driver you can use 10-32 without an issue.  Overkill is usually good; however, the bolt still needs to go through the trim ring.  ;)