
Subject: Re: 4pi flat pack, Rhino Line
Posted by [jtwrace](#) on Tue, 15 Sep 2020 21:14:33 GMT
[View Forum Message](#) <> [Reply to Message](#)

tubino wrote on Tue, 15 September 2020 16:05Thanks for posting these details! It's very useful for me. Did you use 10-32 for the t-nuts, or 1/4" x 20?

1/4"-20 Tee Nuts for my driver. However, if you are using a small Waveguide or driver you can use 10-32 without an issue. Overkill is usually good; however, the bolt still needs to go through the trim ring. ;)
