Subject: Re: 3Pi and 4Pi Plans Request
Posted by OutOfSpace on Wed, 23 Sep 2020 14:46:25 GMT
View Forum Message <> Reply to Message

Endo, the number of clamps you need depends on the details of how the pieces fit together and how many pieces have to be clamped at a time. My guess is a minimum of 4 (one for each opposing corner).
Butt joints verses miter joints verses using screws instead of clamps make a difference as well.
Are you going to sand, fill, sand, and paint, or do you want a natural wood finish? You'll have to think those details all the way through, and dry-fit everything so you know what to do once you have glue on the joints. You don't want to be figuring that out while the glue is drying.
As for your question about the cost of the kits, they are vastly cheaper than getting a usable table saw. It's possible to use a circular saw with a guide to get good cuts, but in all cases, practice before trying to build your first speakers. MDF is cheap enough to make that practical.

Chris