

---

Subject: Re: questions

Posted by [PakProtector](#) on Fri, 25 Nov 2005 22:45:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

hmmmm...push-pull-parallel 6V6's. Plus the pre-amp tubes. Say 160 mA at between 275 and 325 volts. Pick your filter type, and rectifier and PSUDii will spit out the rest. You were not quite clear in the original post. You wish to make one more of these? Or you're going to rebuild one with a bad power TX? Instead of parallel 6V6, I'd suggest single pairs of 6L6GC. cheers, Douglas

---