Subject: Re: 4 Pi Build in San Luis Obispo - Settings for Flanking Subs
Posted by Wayne Parham on Tue, 20 Jul 2021 15:52:09 GMT
View Forum Message <> Reply to Message

It never hurts to use a high-pass filter for vented subs set at or just below the Helmholtz frequency. So if your sub cabinets are tuned to 20Hz, set a fourth-order high-pass at 15-20Hz.