

---

Posted by [Wayne Parham](#) on Tue, 19 Apr 2022 14:49:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I like using T-nuts, 10-32 size with button head or hex head screws. The screw head should go through the cork and apply clamping force directly to the cast basket frame. Also, when installing the T-Nuts, don't just tap them in because that often just bends the tangs. See the notes in the link below:

[Mounting Screws and T-nuts](#)

---