

---

Posted by [Wayne Parham](#) on Sun, 26 Jun 2022 01:03:03 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Don't panic, because I don't think you've ruined them. But don't force them either. Take the extra effort to go get that tap and use it on each of the T-Nuts. They're super-easy to use - just like threading in a screw - but the tap is hardened steel and has cutting edges that will remove any burrs and put the threads back in place. You'll be glad you did it.

---