

---

Posted by [Wayne Parham](#) on Mon, 27 Jun 2022 13:49:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

That's perfect. It'll work just fine that way.

You can put it on the side of the cabinet too, if you prefer. But I think the way you've shown above is easiest, and it works just fine.

Put a gasket underneath the Zobel resistor and the crossover PCB too. It will cushion them and prevent any possibility of buzzing. You can use cardboard, cloth or PVC sheet material.

---