Posted by Wayne Parham on Tue, 28 Jun 2022 19:50:56 GMT View Forum Message <> Reply to Message

I hear you on the screws into MDF. When I use wood screws on MDF, I limit the clamping force to "just a smidge" - 'cause that's all you can really expect from MDF. But then again, you don't need any clamping force for the crossover board. It just needs to be attached.

The insulation looks perfect to me.

And everything else does too! Good job!

