
Subject: Re: Subs for floorstander and corner horns
Posted by [Wayne Parham](#) on Wed, 08 Mar 2023 19:20:26 GMT
[View Forum Message](#) <> [Reply to Message](#)

Here you go:

LAB12 spec sheet

That shows overall diameter and baffle hole diameter, which can be used to determine the width of the routed groove. Depth, on the other hand, isn't listed there. But the depth should be to 5/8" to 3/4" to make the driver appear flush.

The rubber surround actually protrudes past the front gasket, even when the driver is at rest. So to make the gasket flush, you would want a 5/8" depth recess. To get the surround to be flush, you'd need a little more depth, about 3/4".