Subject: Re: Am I in the Right Place?
Posted by Wayne Parham on Fri, 07 Apr 2023 13:20:58 GMT
View Forum Message <> Reply to Message

You've got mail!

You'll want the spacing between horn and midwoofer to be as close as possible to provide a tall forward lobe. Watch the "Vertical Nulls" video in the "Crossover optimization for DI-matched two-way speakers" link I posted above, earlier in this thread.

I would suggest placing these speakers on stands and adding flanking subs. Maybe start with just the main speakers now, and add flanking subs later. And I'd use a passive crossover on the mains, and drive them with your tube amp. Flanking subs can be driven with plate amps.