

---

Subject: Re: My 4 Pi Build

Posted by [Wayne Parham](#) on Fri, 10 Nov 2023 20:21:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The compression driver mounts onto the horn with a couple of 1/4-20 bolts that are spaced 3" apart. Each mounting bolt is 1-1/2" from the center. Some call this the "standard two-hole mounting pattern."

In the case of the B&C DE-250, you could use 1/4-20 bolts but they include a couple of studs and nuts with that compression driver so I personally always use 'em.

---