Subject: How about this
Posted by Shane on Thu, 09 Nov 2006 15:12:05 GMT
View Forum Message <> Reply to Message

Thanks John. The reason for the 10H chokes is because that's what I happen to have. LOL!!How about this. Use the 10H choke first with a 40uF cap, then branch off with individual 4H chokes and another 40uf cap per channel?Also, I've seen where some have put a very small value cap between the rectifier and PT secondaries? But obviously no way to model this in PSUD.