

---

Subject: How about this

Posted by [Shane](#) on Thu, 09 Nov 2006 15:12:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks John. The reason for the 10H chokes is because that's what I happen to have. LOL!!How about this. Use the 10H choke first with a 40uF cap, then branch off with individual 4H chokes and another 40uf cap per channel?Also, I've seen where some have put a very small value cap between the rectifier and PT secondaries? But obviously no way to model this in PSUD.

---