

---

Subject: 3 & 4 pi inductors

Posted by [mrkazador](#) on Tue, 17 May 2011 21:10:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I see in the 3 & 4pi crossovers that 20awg is the minimum for inductors. What difference is there going with all 18awg or even 15awg?

Thank you

---

---

Subject: Re: 3 & 4 pi inductors

Posted by [Wayne Parham](#) on Tue, 17 May 2011 21:36:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

When you go with larger diameter wire coils, DC resistance is reduced and the end result is bass will tighten up just a little bit. We use 18 guage in stock builds, and 15 guage is a recommended upgrade option.

---