
Subject: Screws

Posted by [dutchswan0311](#) on Thu, 22 Mar 2012 20:23:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

Elementary... I know...but...

Are there best practices on how to screw the 8" woofer and the tweeter to the 1pi enclosure?
T-nuts and headcap screws? Sheetrock screws lol?

Subject: Re: Screws

Posted by [Wayne Parham](#) on Thu, 22 Mar 2012 22:24:52 GMT

[View Forum Message](#) <> [Reply to Message](#)

For the larger speakers I like T-Nuts but for the little ones, I like black #6 screws. Sometimes #8 are OK too, but I generally prefer #6.

Here are some from Parts Express:

#6 x 3/4" Deep Thread Pan Head Screws, Black Finish

#8 x 3/4" Deep Thread Pan Head Screws, Black Finish
