

---

Subject: Splicing Wires

Posted by [Vaiger](#) on Tue, 02 Aug 2016 09:27:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It happens.....something runs over, or otherwise chews through, your speaker wires and you have to splice them together to get them to work again. Are you a "twist and tape" kind of person, or do you get your solder kit out, call out from work and block all phone calls until the job is done?

---

---

Subject: Re: Splicing Wires

Posted by [Nouri](#) on Wed, 03 Aug 2016 13:18:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm all about the twist and tape method. It's always just a quick fix though because I always end up buying new wire to replace it.

---

---

Subject: Re: Splicing Wires

Posted by [mamoss](#) on Wed, 10 Aug 2016 04:58:15 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I am also a twist and tape person but that will be just be in the short term. The probability that they will stop working soon after is high when you just tape them so it is always best to solder them.

---

---

Subject: Re: Splicing Wires

Posted by [Thaddeus](#) on Thu, 01 Sep 2016 11:35:17 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

If I'm in a hurry and I don't have the time I'll just twist and tape them together. Other times I've used heat shrink connects and that seems to get the job done a little more permanently.

---