

---

Subject: Subwoofer Wires

Posted by [AlMayzing](#) on Wed, 19 Jul 2006 16:15:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I have a Gigaworks S750 system I am not very good with this kind of stuff it recently blew up so I bought a new one it is essentially a power amp-subwoofer box which supplies the other speakers I didn't want to throw away the old one so I took out all of the amp components to leave me with a speaker in a box. My problem is that there are 3 pairs of wires going to the speaker and I am not sure why and so I don't know how to wire it up. Should I put a power amp in the box and then use sub pre out from an integrated amp separately or should I just wire the speaker up to an integrated amp? Can anyone help? Thanks in advance

---