
Subject: what are power extremes/ or nominal power to be....

Posted by [ARTIdaho](#) on Thu, 24 Nov 2005 21:59:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

expected for single drive speakers? I am fairly new (and lurking) to the concept and use a 70 + Technics SU 8600 integrated amp and would like to build a BLH using a 8" Fostex or something in that order.

Subject: Re: what are power extremes/ or nominal power to be....

Posted by [roncla](#) on Fri, 25 Nov 2005 14:35:17 GMT

[View Forum Message](#) <> [Reply to Message](#)

Depends on the efficiency of the driver/horns and the SPL level you desire. I am running 5 watt battery P/S gainclones on my horns using the Fostex 208e sigma and a ribbon tweet. Use to be a 206e and i was running 24 watt SMPS P/S gainclones and found the volume position to be a bit touchy. The SPL would have a tendency to jump up or down according to the recording. I have a far greater control and a much more tube like sound at the lower voltage P/S. With the efficiency of the horns i really dont believe more than 10 watts is necessary, but thats MHO.ron

Subject: Re: what are power extremes/ or nominal power to be....

Posted by [akhilesh](#) on Fri, 25 Nov 2005 22:35:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

I'd build the speaker first, and try it with your current amp. Then, if you like, you can try a SET amp. But first, it would be good to hear the speaker and see if you like it. Changing to a SET amp will make a difference, but not a huge one. Hope this helps. Just my 2 cents. -akhilesh