

---

Subject: Re: Crossover Electronics 101  
Posted by [akhilesh](#) on Fri, 02 Feb 2007 13:25:31 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Thnaks Wayne. So it seems the impedance of the drivers at the frequnecies in question is sufficient, and adding the series padding resistor to the impedance of the tweeter will work. This will limit the number of crossover parts one needs to buy. -akhilesh

---

---

Subject: Re: Crossover Electronics 101  
Posted by [Wayne Parham](#) on Sat, 03 Feb 2007 02:53:45 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I've found that a shunt (parallel) resistance of 1.5x to 3.0x the DC resistance of the tweeter is modes.

---

---

Subject: Re: Crossover Electronics 101  
Posted by [akhilesh](#) on Sat, 03 Feb 2007 12:34:38 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Thanks for the tip, Wayne. -akhilesh

---