

---

Subject: a baffling question

Posted by [lon](#) on Fri, 28 May 2004 05:48:11 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I've done some temporary mounts of the new Tangband W3-871son a small birch ply baffle. The hardware store(s) I checke didn't seem to have anyblack naoldized screws with round heads, si got some flatheadwoodscrews which do not mound flush but looked to be aboutthe right size. Is there someplace like McFeeley's that the right sortof exact match screws for things like these speaks whichcame with none... no docs either... can be found? A dollar's worth of screws and \$5 shipping or something. There must be a better way/alternative.

---

Subject: Re: Unfortunately.....

Posted by [BillEpstein](#) on Fri, 28 May 2004 08:59:35 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

.....the screws you need come from P.E. or McMaster Carr or McFeeley's. Expensive with shipping but at least you'll have them on hand and they're good for mounting sub amps, crossovers, etc.

---

Subject: Re: Unfortunately.....

Posted by [lon](#) on Sat, 29 May 2004 04:39:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'll have to put the screws on some larger order and makedue for now. However, when I was at the local hardware store (one of'em anyway) I ran across square head screws as a astockingitem there. There's lots of talk about these all the time includingprops from one guy who has a construction piece in the current (June/'04) \_audioXpress\_. These look like they need power equipment to be used properly. Is anybody here using the square head screws like theseand the ones shown in McFeeleys ads in \_aX\_?

---

Subject: Two alternatives

Posted by [wunhuanglo](#) on Mon, 31 May 2004 14:46:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

1. Buy any screw you want in the hardware store. Stick them into a piece of foam and spray paint them with a quality paint (Rustoleum? Krylon comes in every sort of black imaginable) to color the heads.2. Buy any screw you want in the hardware store. After install, use a "paint pen" from a

crafts-type shop (not a permanent marker) to color the heads.

---

---

Subject: Re: Two alternatives

Posted by [lon](#) on Mon, 31 May 2004 19:01:46 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Good suggestions but I guess that I think that a nonanodized screw would just mean that a lot of assembly,disassembly etc would wear the paint of pretty fast. I'm surprised there hasn't been any answer on usingsquare head screws. :-|

---

---

Subject: Re: Two alternatives

Posted by [wunhuanglo](#) on Wed, 02 Jun 2004 09:31:32 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I think if you reflect on it, the in-and-out thing probably isn't that big a deal. If you really do use them constantly that way, you'll probably bugger up the heads in short order and replace them anyway.I use square-drive screws sometimes, because I got them at a lumber yard going-out-of-business sale. They're fine really, just too expensive for me given that I get along just as well with phillips head. Can't beat the square drive for no-slip though.

---